



Please read the instructions completely before beginning the installation.

Lyra Collection
Model Number: 1050MP




Lyra Collection
Model Number: 1050PF



Flush both supply lines before installation, then shut off both supply lines.
Minimum hole size for the spout and handle trim is 1-1/4" and maximum of 1-1/2"


HANDLE TRIM INSTALLATION

- 1 - Unscrew pre-assembled handle trim from the valve body. Keep the sleeve adaptor on the trim. Hot valve assembly "Red" to be mounted on left. Cold valve assembly "Blue" to be mounted on right.
- 2 - Remove the fiber gasket from the valve body. Keep the steel washer, brass tube, and lock nut on the valve body.
- Apply a ring of silicone caulking around the handle hole on deck top.
- 3 - Placed fiber gasket back onto the valve body.
- Screw in the valve body into the sleeve adaptor.
- 4 - Align handles with respect to the spout, unscrew a little bit of valve body if needed, and tighten bottom lock nut until secure.



SPOUT TRIM INSTALLATION

- 1 - Remove the tee connector and spout mounting hardware from quick connect shank being sure to leave on brass plate.
- 2 - Apply a ring of silicone caulking around hole designated for spout.
- DO NOT USE PLUMBERS' PUTTY, WHICH CAN DAMAGE FINISH.
- 3 - From the top of the deck, slip the quick connect shank through the assigned spout hole.
- 4 - Secure the quick connect shank by putting the washer and lock nut back on the shank. Tighten the lock nut firmly.
- 5 - From the top of the deck, slip the spout with the flange and flange washer onto the quick connect shank top. Align the spout and tighten the set screw with the Allen key provided.
- 6 - Connect the tee connector to the spout shank.



The measurements shown are for reference only. Products and specifications shown are subject to change without notice.

www.santecfaucet.com | P: 310.542.0063 F: 310.542.5681