

## WATERMYRK

## MPU6 Soft Touch Lavatory Drain Without Overflow

## **Parts Breakdown and Dimensions**





ITEM NO.	DESCRIPTION	QTY
1	Cap	1
2	Cap Gasket	1
3	Plunger	1
4	Body	1
5	Top Gasket	1
6	Bottom Gasket	1
7	Washer	1
8	Nut	1
9	Tail	1

MPU6 Soft Touch Lavatory Drain Without Overflow

STEPS				
1. Unscrew the tail from the body.		2. Unscrew the nut and remove the washer and the bottom gasket from the body.		
3. Place the rest of the drain into the sink from the top. If the cap has a Watermark logo on it then make sure to align it to the desired orientation.		4. Place the bottom gasket on top of the nylon washer, then place the nylon washer on top of the nut, finally screw the nut back onto the body. Do not over tighten the nut.		
5. Apply Teflon tape to the thread on the tail and		6. Connect the drain to the trap and check for		
screw the tail back into the body.		leaks.		

## IMPORTANT INSTALLATION INFORMATION

- USE TEFLON TAPE OR PIPE SEALANT FOR THREADED CONNECTIONS
- DO NOT USE PLUMBER'S PUTTY ON ANY OF THE BRASS COMPONENTS
  This will cause the finish to tarnish. A non-corrosive Alkoxy Silicone is recommended.
- DRAINS ARE ONLY UNDER WARRANTY FOR MECHANICAL FAILURE, NOT FOR FINISH DEFECTS

For technical support, please call 718-257-2800